# AC / DC "CT" STYLE RS485 MODBUS RTU OUTPUT ENERGY METER



SEED

TYPES: QI-POWER-485 50 Amps AC/DC, 800VAC or 1000VDC QI-POWER-485-LV 50 Amps AC/DC, 80VAC or 100VDC

#### **FEATURES**

- **Primary current 0-50 Amps**
- Voltage up to 800VAC or 1000VDC
- Voltage up to 80VAC or 100VDC (LV version)
- Universal AC 1-400Hz or DC measurement
- **Output RS485 MODBUS RTU**
- Measures Volts, Current, Watts, VAr, VA, Voltage Peak Current Peak, Hz, COS, KWh import, KWh export, THD
- Class 0.5 accuracy (voltage, current, active power)
- **TRMS** measurement
- Screw mounting or Din rail mounting
- Fast response time

## **DESCRIPTION**

The QI-POWER-485 and QI-POWER-485-LV are moulded case high accuracy "CT" style universal DC or AC multi parameter energy meters and are galvanically isolated from the measuring circuit. The "CT's" have a primary current range of 0-50 Amps AC/DC and for voltage up to 800VAC or 1000VDC (LV version 80VAC or 100VDC).

The "CT's" are equipped with RS485 MODBUS RTU communications. Measuring parameters include Volts, Peak Volts, Current, Peak Current, Watts, VAr, VA, Hz, COS, KWh import, KWh export & THD.

Via the RS485 the "CT's" are fully configurable with the aid of free software supplied, for example response / filtering times can be configured, along with minimum current and power thresholds (below these values the device cuts off and the measured value is zero. The Baudrate is selected via dip-switches.

The "CT's" require a supply voltage of 9 to 30VDC and has an internal aperture size of 15mm Dia.

The principle of putting in primary turns on CT's to reduce the primary current range also applies to these current transformers.

#### SPECIFICATIONS

9 to 30VDC Supply voltage: Power consumption: < 1.3 W

Accuracy: @ 25°C up to 200 Hz

Class 0.5 (I, V, W) Frequency +/-0.1Hz

Resolution: 12 bit <200 ppm/°C Temp coefficient: Operating temp: -15 to  $+65^{\circ}$ C 10-90 %RHt **Humidity:** 

RS485 MODBUS RTU Output: **Baudrate:** 1200....115200 Baud Sampling rate: 11K samples per second Input impedance: 1M 0hm +/-1% Screw or Din rail Mounting:

50 Amps AC/DC Max measurement range:

800VAC or 1000VDC

2 way

80VAC or 100VDC (LV version)

1-400Hz AC frequency range:

Dip switch:

Isolation:

Measuring parameters: Volts, Peak Volts, Current,

> Peak Current, Watts, VAr, VA Hz, COS, KWh import & export, THD min & max each reading 3KV current measurement


4KV voltage measurement

On an uninsulated conductor

Indication: Via yellow LED

> Supply voltage present - steady Data communicating - flashing

Terminals: 4 way & 2 way removable plug



# DIP SWITCH TABLE

Dip switch settings	1	2
All setting from EEPROM	0	0
Set Address 1 -Baud 9600	1	0
Set Address 1 -Baud 38400	1	1

#### ORDERING INFORMATION

OI-POWFR-485 P/No.

QI-POWER-485-LV (Low Voltage version)

Tel: 0161 626 5316 / 01276 25858 www.foxtamcontrols.co.uk

### QI MODBUS REGISTER TABLE & DIP SWITCH TABLE

REGISTER NAME	EGISTER NAME COMMENT REGISTER TYPE		R/ W	DEFAULT VALUE	RANGE	MODBUS ADDRESS	
Machine_ID	ID machine	Unsigned 16 bits	R	16		40001	
FW_VERSION	Firmware Release	Unsigned 16 bits	R			40002	
addr	MODBUS ADDRESS	Unsigned 16 bits	R/W	1	1250	40003	
Delay	Answer Delay	Unsigned 16 bits	R/W	1	11000	40004	
Baudrate	Baudrate 0=1200 / 1=2400 2=48000 / 3=9600 4=19200 / 5=38400 6=57600 / 7=115200	Unsigned 16 bits	R/W	1	17	40005	
parity	Type of parity 0=8,N,1 1=8, O, 1(ODD) 2=8, E, 1(EVEN)	Unsigned 16 bits	R/W	0	02	40006	
In_start	Start Input	Floating 32 bits	R/W	0		40007 (LO) 40008 (HI)	
In-Stop	Stop Input	Floating 32 bits	R/W	300 AC/DC		40009 (LO) 40010 (HI)	
Out_start_V	Start Output (mV)	Unsigned 16 bits	R/W	0	1 10000	40011	
Out_stop_V	Stop Output (mV)	Unsigned 16 bits	R/W	10000	0 10000	40012	
flit1	no of samples for mobile average (1=100ms)	Unsigned 16 bits	R/W	1	132	40013	
flit	Second level filter for ripple problems on AC measurement	Unsigned 16 bits	R/W	4096	1000 20000	40014	
Cutoff	Cutoff value (A)	Unsigned 16 bits	R/W	1500		40029	
RMS_A	RMS Current Value	Floating 32 bits	R			40037 (LO) 40038 (HI)	
status	Status Register bit 0=1: Error flash setting bit 1=1: Errorflashcalibration bit 2=1: Over Range bit 3=1: Under Range	Unsigned 16 bits	R			40048	
RMS_100	RMS Value of Current (A x 100)	Signed 16 bits	R			40050	
RMS_sw	RMS Current Value @ swapped	Floating 32 bits	R			40051 (HI) 40052 (LO)	
Ah	Ah counting (resettable)	Floating 32 bits	R/W			40053 (LO) 40054 (HI)	
A_MAX	Max current value/100 (resettable)	Signed 16 bits	R/W			40055	
A_min	min current value/100 (resettable)	Signed 16 bits	R/W			40056	
Data High	Calibration Data (yy,mm)	Unsigned 16 bits	R			40057	
Data Medium	Calibration Data (day, hour)	Unsigned 16 bits	R			40058	
Data Low	Calibration Data (min, sec)	Unsigned 16 bits	R			40059	



DISCRIPTION	1	2	3	4	5	6	7	8
All setting from EEPROM	0	0	0	0				
ADD= 1	0	0	0	1				
ADD= 2	0	0	1	0				
ADD= 15	1	1	1	1				
2400 BAUDRATE					0	0		
9600 BAUDRATE					0	1		
38400 BAUDRATE					1	0		
57800 BAUDRATE					1	1		
MONOPOLAR (TRMS)							0	
BIPOLAR (MEAN VALUE)							1	
300 A AC/DC								0
150 A AC/DC								1


#### **Dip-Switch Settings**

**Example**: if you want to set the measured range from 0...300 A AC/DC to 0... 150A AC/DC, switch ON the dip-switch n°8 and switch ON also one of the first four dipswitches (if you don't do that it will continue to take the EEPROM setting).

If you want to change from uni-polar (default) to bi-polar function by dip-switch, switch ON the dip n°7 and switch ON also one of the first dip-switches (if you don't do that it will continue to take the EEPROM setting).

Any changes made by the dip-switches it is required to switch off the power supply. It's a safety condition in order to prevent any damage to the device.

#### CONNECTION DIAGRAM FOR QI-POWER-xxx



### SOFTWARE DOWNLOADS

To enable programming, setup and configuration the following two free software downloads are available from www.qeed.it (section products/download software). Java required.

#### **Software Download**

FACILE-QI-POWER-485

FACILE-QI-50-V-485

For QI-50-V-485 & QI-300-V-485 For all QI-POWER-xxx variants

# **STANDARDS**

EN61000-6-4/2006 + A1 2011; EN64000-6-2/2005; EN61010-1/2010 EN55022: 2010-12; EN55024: 2010-11;

EN61000-6-4/2006 + A1 2011; EN64000-6-2/2005; EN61010-1/2010

CE Marked and UL pending on (some types)

Tel: 0161 626 5316 / 01276 25858