

Installing Designer Wall Panels

Installation is straight forward. Use a sharp, fine toothed hand saw to cut to size and mount using Decorgrip Plus. Use butt joints and do not grout or fill the joints, so joints should be left visible. If you have a visible end you are likely to have some visible cavities that will need filling. Use Decorgrip to fill these for the perfect finish.



1. Measure out the wall and define the position of the panels.



2. Apply Decorgrip Plus adhesive.



**3. Position the panel
(spacers recommended for
Designer Panels 1 & 2).**



4. Continue installation to your layout.



5. Apply paint.